



Contents

3
4
5
6
7-9
10
11
11
12
13
14-17
18-19
20-21
22
23
24
24-25

Product Specifications

Bluetooth® Specification: V4.0 with apt-X and noise cancellation

Backward compatible with v3.0, v2.1,

v2.0 & v1.2

Bluetooth® Profiles Supported: HFP v1.6 wideband speech (HD voice

ready), HSP v1.2, A2DP v1.2,

AVRCP v1.4

Up to 265 hours

Operating Distance: 10 meters with no obstructions

Operating Temperature: 0-50 degree celsius Charging Time*: Around 1.5 hours Talk Time*: Up to 7.5 hours Music Time**: Up to 6.5 hours

Standby Time*: Battery Type and Capacity:

Battery Type and Capacity: Rechargeable Li-Polymer 110mAh

Dimension: $55(L) \times 25.5(W) \times 15(H) \text{ mm}$

Weight: 21g

^{*}May be varied by mobile phone settings and operator


^{**}Music time is included game playing time and others media using time

Components

Thank you for choosing the iXchange UA-28SE Retractable Stereo Bluetooth® Headset. We hope you enjoy it! Inside the package, you should find:


- 1 UA28SE headset
- 1 USB saver charger
 1 USB Cable
- 1 USB Cable
- 1 Neck Strap
- 1 Earphone cable with the micro USB plug
- 1 Micro USB / 3.5mm female plug connector
- 1 Manual
- 1 Pouch
- 2 sets L/S inear cushion

UA-28SE Overview



Retractable Mechanism

The earpiece cord can be extended by gently pulling on the cord. The cord can be retracted (shortened) by pressing the Rewind Button.



How to Wear Your Headset

UA-28SE is designed,

A. to clip onto your clothing, or








How to Wear Your Headset (cont'd)

B. fasten by a neck strap to wear comfortably and securely around your neck



Step 1. Loop the thin end of the neck strap through the slot on the Headset.

Step 2. Loop the thicker side of the neck strap through the loop created by the thin wire and pull until snug.

Step 3. Once pulled through, you can wear your Headset around your neck.



How to Wear Your Headset (cont'd)

B.



To release the strap, hold the strap and pull outwardly. (See the picture on left)

- · Use the provided neck strap only.
- \bullet It may be necessary to bring the microphone closer to your mouth for lowering background noise.

Charging Your Headset

Before using your UA-28SE ("Headset") for the first time, please plug the charger into the power source and connect the other end to micro USB charging socket of headset to charge the battery fully.

Status	Status Indicator	Audio (Earpiece)
1. Charging	Red light ON	No sound
2. Fully charged	Blue light ON	No sound
3. Low battery	Red light for every 5 seconds	A short beep every 20 seconds
4. Out of battery	OFF	No sound

- Use only the supplied charger for charging
- To extend the battery life, re-charging the battery every 6 months.
- Charging indication will be delayed in a few seconds if the headset has not been used for a long period of time.

Getting Started

Turning Your Headset On and Off:

A. Turning on

Press and hold the MFB until the status indicator flashes blue. For the first time (or after Reset), the headset will go to the Pairing Mode directly (the indicators flashes blue and red alternately).

B. Turning off

Press and hold the MFB until the status indicator flashes red.

Pairing Your Headset with a Bluetooth® wireless technology enabled device

- 1. Turn on the Bluetooth® function in the device.
- Place the headset and the device where they are visible, within arm's length from each other.
- 3. Ensure the headset is OFF.
- To activate the device's pairing mode, press and hold the MFB until the status indicator flashes blue and red alternately.
- Search the headset, select "UA-28SE" and enter the passcode "0000". If your device supports "Simple Pairing" function, no code is required.
- 6. When the pairing is complete, the headset's status indicator will flash blue.

Pairing Your Headset with Two Bluetooth® wireless technology enabled devices (Multi-point)

UA-28SE supports a Multi-point function to allow simultaneous pairing of the headset with two devices.

- Pair the headset with the first device (follow the step in "Pairing Your Headset with a Bluetooth wireless technology enabled device").
- 2. Turn off the headset and the Bluetooth® function of the first paired device.
- Pair the headset with the second device (follow the step in "Pairing Your Headset with a Bluetooth wireless technology enabled device").
- Activate the Bluetooth connection with the headset and the first paired device on the device's menu. Or turning on the headset again then it will connect two devices automatically.
- For some devices, you may need to manual press "connect" to connect the headset.
- If the pairing cannot be completed within two minutes, the headset will automatically go to standby mode and then turn off after five minutes. Repeat steps to pair both devices again.

Reconnecting Your Headset

- If the headset has been powered off, it will reconnect to the phone automatically after turning on the headset, if not, press reconnect on the phone.
- If the phone has been powered off and headset is then disconnected, reconnect the headset by phone's menu when phone turns on again. Otherwise, turns on the headset again.

Using Your Headset

Function	Button	Audio (Speaker)	Status Indicator
Incoming Call		Ringtone (Musice will stop durung incoming call)	Blue light flashing 3 times in every 3 seconds
Answer a Call (Standby mode / music playing mode)	Press MFB once to accept		During the call, blue light flashes in every 5 seconds
Answer a Second Call	Press MFB once to end the current call and accept the second Call Press and hold Vol + once to hold the current call and accept the second Call		During the call, blue light flashes in every 5 seconds
Call Reject	Press the MFB twice	'Di Do' tone once	Blue and red light flashing 2 times in every 3 seconds (Miss call alert)
Reject a second call directly on the other connected phone during the call.			
End a Call	Press the MFB once	'Do' tone once	Blue light flashes once
Mute / Unmute	During the call, press the Volume + twice / During the call, press the Volume - twice	'Do Do' tone when the call is muted	
Mute/Unmute function is not work during three party communication.			
Hold / Unhold	During the call / call holding, press and hold the Volume +	'Do' tone once	14

Using Your Headset (cont'd)

Function	Button	Audio (Speaker)	Status Indicator
Voice Dialing	Press and hold the MFB until a short beep	'Do' tone once	
After you hear a short Voice redialing is only mobile phones.	t beep, say the voice tag, and you mus allowed for those saved voice tag into	t have the voice tag re the 1st connected ph	ecord on your mobile phone. one if you have connected two
Last Number Redial (Standby mode / music playing mode)	Press the MFB twice	'Do' tone once	
Redial the call from the	e 1st connected phone if two mobile p	hones are connected.	
Reset / Remove the pairing history	Press and hold the MFB and Volume +	'Do Do' tone once	Red light flashes once
Out of range alert		'Di Do' tone	In first 1 min, blue light flashes once in every 10 seconds, then flashing 2 times in every 3 seconds

The headset will automatically reconnect within 5 minutes, otherwise it will off. If auto-connect is not supported, press the MFB once.

Using Your Headset (cont'd)

Function	Button	Audio (Speaker)	Status Indicator
Miss call alert			Blue and red light flashing 2 times in every 3 seconds
Release miss call alert	Press the MFB once	"Do" tone once	
Adjust Volume	Press the Volume +/- once to increase or decrease by 1 level (Total 8 levels)		
Standby mode without mobile connection (No network covered)			Blue light flashing 2 times in every 3 seconds
Standby mode with mobile con- nection			Blue light flashes in every 10 seconds

Using Your Headset (cont'd)

 UA-28SE is designed to work with the mobile phones with Bluetooth Handsfree profiles (or Bluetooth devices), the compatibility of some features are not guaranteed for some phones in different operating system.



In order to have a better and clear reception, there should have no obstacle to the headset while talking.

Listening the music

Enjoy the music in two ways:

A. By a earphone cable (provided)

Step 1: Connect the provided earphone cable to the micro USB socket

Step 2: Enjoy the music with the earphone and the retractable earpiece



B. By your own headphone

Step 1: Connect the provided micro USB / 3.5mm female plug connector to the micro USB socket

Step 2: Enjoy the music with your own 3.5mm headphone



Note:

No sound from the retractable earpiece in this way, using the headset by your own headphone

Listening the music (cont'd)

Function	Button	Audio (Speaker)	Status Indicator
Play a music	Press directly from phone	Music	No indicator light
Stop playback	Press the hold MFB for 2 seconds		
Forward / Backward during playback	Press and hold the Vol + / - for about 2 seconds		

Troubleshooting

I cannot pair with my mobile phone

- Ensure your headset is power on and fully charged
- Ensure the Bluetooth setting is activated on your phone
- Ensure the headset is at pairing mode (flashes blue and red alternately)
- Ensure the headset is not out of range of your phone

If the above steps do not solve the problem, please turn off the headset and recharge the headset, and then try again.

I cannot hear the sound in my headset

- Ensure your headset is power on and fully charged
- Ensure your headset is paired and connected with your phone
- Ensure the conversation is not transferred to your phone
- Ensure the volume level is high enough

I cannot turn off the headset

Please press and hold the MFB for a longer time, otherwise, please recharge the headset for 2-3 seconds then disconnect the charger, the headset now turns off.

I cannot turn on the headset

Ensure your headset is power on and fully charged, otherwise, please charge the headset for 1-1.5 hours, and then turn on again.

Troubleshooting (cont'd)

My phone cannot be auto-reconnected with the headset

- Manually connect the headset from your mobile phone
- Turn off the mobile then turn on again
- Turn off the headset then turn on again

If the above steps do not solve the problem, turn off the headset and reset it, pairing the headset again.

I hear a "Beep" sound during the call, what happen?

Low battery alert, please charge your headset.

I hear some noise during the call, why?

There is an obstruction between the headset and your mobile, please remove it. Or please put your mobile on the table, don't hold it on hand.

My headset is out of battery after listen the music just a few hours, why? Music time is included game playing time and others media using time, so battery will be used not only on playing the music. please charge your headset when there is "Low Battery" alert.

Safety Precautions

- Unintentional depression of the retractable button could result in an injury from the force of the earpiece cord retraction.
- Be careful when retracting the length of the earphone. Keep a safe distance between your face and the headset.
- If you must use the headset while driving, ensure your attention is fully focused on driving safety. Be a responsible driver and abide by the local laws.
- Place in a children's unreachable area, never allows them to play with the headset. Small parts pose as a choking hazard.
- Obey all designated areas such as hospitals, electronically restrictive and hazardous environment that require an electrical device be switched off.
- Turn off your headset prior to boarding on an aircraft. Do not use it while being asked by the flight attendant.
- Never mount or store your headset over any air bag deployment area as serious injury could result upon deployment.
- Do not attempt to disassemble the headset as it does not contain serviceable components.
- Headset builds with battery inside and should dispose of it according to local regulations, not as a household waste.

Maintenance

- 1. Do not yank or forcibly pull the earphone cord.
- Consider turning your headset off before placing it in your pocket or bag. If the MFB is accidentally pushed, your mobile phone may place an unintended call.
- 3. Do not expose the headset to liquid or humidity, as it is not waterproof.
- 4. Do not use abrasive cleaning solvents to clean the headset.
- 5. Do not expose the headset to extremely high or low temperatures.
- Do not expose your headset to contact with sharp objects as this will cause scratches and damage.
- Do not stick anything inside the headset as this may damage internal components.
- Do not attempt to replace the headset's battery. It is built-in and is not removable.
- 9. Use only the manufacturer supplied charger when charging the headset.
- 10. Do not disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the headset is subsequently used.

Declaration of Conformity

We, iXchange, declare that the following product:

Model No.: UA-28SE

is in conformity with the following essential requirements of Council Directive 1999/5/EC (referred to as R&TTE Directive): Article 3.1a, 3.1b and 3.2 and the product is manufactured in accordance with Article 11 of the directive.

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.

15.21

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Statement (cont'd)

15.105(b)

This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna
- · Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help





Made in China